

## Release Notes

### NOVA 2

Version: 2.0.6

Date: 20<sup>th</sup> of May 2011

---

#### This document applies to the product

- Eclipse

It gives you an overview about the improvements of version 2.0.6.

---

Dear customer,

Having successfully passed the major events in France, Belgium, Poland, Czech Republic and Germany during the Sennheiser annual Global conference, the Archive European Tour and the Ibrahim Maalouf Jazz concert in Brittany, it is a real pleasure for us to provide you this very improved NOVA 2.0.6 release.

#### Spike Jones mixing and recording in full digital the symphonic orchestra during Archive concert in Berlin – April 2011



---

**Eclipse installed into Czech Radio OB Van - Czech Radio Ceske Budejovice – 2011**

## New Fixes

### I - Additional improvements included in Nova, version 2.0.6

#### 1) Several bug fixes

NOVA 2.0.6 improves the stability of the Eclipse considerably. If your system software is based on Nova 1.1.5 or 2.0.2, we strongly advise you to update NOVA and M.A.R.S Bios as well as their operating system. All instructions are part of the NOVA 2.0.6 update files from our website.

#### 2) Ethersound devices management

NOVA 2.0.6 fixes the majority of the problems regarding the third party and new Ethersound devices detection and management. This concerns the DMI-8 from Neumann as well as the SR-16 from INNOVASON.

#### 3) The new channel's parametric EQ (including shelving and filtering)

Users reported that some values and behaviours were not correct. This has been fixed on 2.0.6.

#### 4) "On the flight" stereo management

The transformation of a mono channel to a stereo channel, executed by mistake, caused some bad synchronization between the channel mute status and its LED. This has been fixed on 2.0.6.

**5) The Link management**

Some problems related to linked Smart Fads and linked Mutes on stereo channels have been fixed on this release.

**6) Panoramic behaviour on L,R,C busses**

Some problems have been reported on this topic. It has been tracked and fixed on this release.

**7) Channel Libraries**

Single and multi libraries saving and loading have been stabilized by this release.

**8) Inserted Plug-ins**

There was some conditions where the setting of the inserted plug-ins were not properly recalled. This has been fixed on 2.0.6.

**9) The TRIM parameter**

On this release, the TRIM value is now part of the Relax, Copy/Paste and Link selectable parameter.

**10) PAN Curves**

The PAN curve was not correctly updated by files loading. This has been fixed on 2.0.6.

**11) VCA controlling MATRIX**

Fast Feedbacks from users informed us that VCA didn't control the stereo Matrixes. This has been fixed on 2.0.6.

**12) Prev/Next and other switches debouncers**

This topic has been re-entered by this new release.

**13) Aux send @ 0db function activated during patch modification**

During the modification of a patch, this function was activated although it was not expected. This has been fixed on 2.0.6.

**II - Additional improvements included in version 2.2 of the Operating System**

The new KeyMaker 2.2.0 available on our web site is absolutely necessary to reinforce the stability of Nova and M.A.R.S operating systems. Please carefully follow the instructions provided in the zipped file of Nova 2.0.6 and don't hesitate to contact our service department if you need assistance in your update.

**Important note about Desk version**

Please go to the PCB (Personal Console Builder) screen of your console and note the Desk Version information.

If it is not our last version, **4.28**, please contact our Service Department as soon as possible in order to obtain the necessary eeprom and instruction to change it.

The behavior with the previous versions could be :

- Sometime, no detection of the DESK just after boot-up.
- In the Smart Zone, the Smart Fads stay blocked to their position (you have to press their Select Button to force them to go on their requested position).

## Contacting the Service Department

If you feel the requirement of updating your system please contact our service department for clarification if this is advisable or necessary. The staff will coordinate all necessary steps with you. Telephone support can be given during the common office hours (Mon – Fri 9:00 – 17:00 hrs CET) after a date has been arranged. In case you desire further support please contact also our service department.

- Please write an e-mail to: [service@innovason.com](mailto:service@innovason.com) / Tel.: +33 (0) 546 28 94 44 or +49 7222 1002 4900

Your e-mail should include the following information:

- Name and phone number of the contact person as well as the time when this person is available
- Number and type of the system(s)
- Current software

## Copyright

All rights reserved. No part of this document may be reprinted without the express permission of the Innovason SAS.

All trademarks and registered trademarks are owned by their respective holders. We cannot warrant that all brand names, products, trademarks, claims, regulations, directives, specifications and standards contained in this document are free from being subject to the property rights of a third person.

In spite of our careful examination we cannot warrant that the contents are free from errors. The Innovason SAS is not responsible for misleading or incorrect information which may possibly be contained in this document.

The Innovason SAS may make changes to specifications at any time and without prior notification.